

Upgrading firmware

Note: To prevent data loss, it is recommended that you backup your data to another location before upgrading the firmware of your DrivePro 100.

1. After downloading firmware from Transcend website, decompress it and then put “FWDP100.bin” in the “SYSTEM” folder in microSD memory card.



2. Insert the microSD memory card that contains a newer version of firmware.
3. Select Upgrade Firmware from the “Settings” menu and press **OK** to start the firmware detection process. The DrivePro will automatically find the new firmware file.